

MODEL

2006

$\phi 19$

MAX  
AC 200A

AC  
V

DC  
V

$\Omega$

•)))  
Continuity

- Pocket size, handy clamp meter.
- UL listed fire retardant plastic housing case.
- Multifunction instrument having voltage and resistance measurement functions in addition to all the ranges incorporated.



# Specifications

MODEL	Model 2031	Model 2002PA	Model 2007A	Model 2006
AC A	20A ±2%rdg±5dgt(50Hz~1kHz) 200A ±2%rdg±5dgt(50/60Hz) ±3%rdg±10dgt(40Hz~1kHz)	400A(0~400A) ±1%rdg±3dgt(50/60Hz) ±2%rdg±3dgt(40~1kHz) 2000A(0~1500A) ±1%rdg±3dgt(50/60Hz) ±3%rdg±3dgt(40~1kHz) 2000A(1500~2000A) ±3.0%rdg(50/60Hz)	400/600A ±1.5%rdg±4dgt(50/60Hz) ±2%rdg±5dgt(40~400Hz)	2/20/200A ±2%rdg±5dgt(2/20A)(50Hz~1kHz) ±2%rdg±5dgt(200A)(50/60Hz) ±3%rdg±10dgt(200A)(40Hz~1kHz)
AC V	—	40/400/750V ±1%rdg±2dgt(50/60Hz) ±1.5%rdg±3dgt(40~1kHz)	400/750V ±1.2%rdg±3dgt(50/60Hz) ±1.5%rdg±4dgt(40~400Hz)	2/20/200/500V ±1.5%rdg±2dgt(50/60Hz) ±1.5%rdg±5dgt(40Hz~1kHz)
DC V	—	40/400/1000V ±1%rdg±2dgt	—	2/20/200/500V ±1%rdg±2dgt
Ω	—	400Ω/4k/40k/400kΩ ±1.5%rdg±2dgt	400/4000Ω ±1.5%rdg±2dgt	2kΩ ±1.5%rdg±2dgt
Continuity buzzer	—	buzzer sounds below 50±35Ω	buzzer sounds below 50±35Ω	buzzer sounds below 300~400Ω
Output Voltage	—	400/2000A DC400mV/200mV	—	—
Conductor Size	φ 24mm max.	φ 55mm max.	φ 33mm max.	φ 19mm max.
Safety Standard	IEC61010-1 CAT. III 300V	IEC61010-1 CAT. III 600V CAT. II 1000V IEC61010-2-031, IEC61010-2-032	IEC61010-1 CAT. III 300V CAT. II 600V CAT. I 1000V IEC61010-2-031, IEC61010-2-032 IEC61326(EMC)	—
Frequency Response	40Hz~1kHz	40Hz~1kHz	40Hz~400Hz	40Hz~1kHz
Withstand Voltage	3700V AC for 1 minute	5550V AC for 1 minute	3700V AC for 1 minute	2200V AC for 1 minute
Power Source	LR-44(1.5V)×2	R6P(AA)(1.5V)×2	R03(AAA)(1.5V)×2	R6P(AA)(1.5V)×2
Dimensions	147(L)×58.5(W)×26(D)mm	247(L)×105(W)×49(D)mm	195(L)×78(W)×36(D)mm	184(L)×54(W)×32(D)mm
Weight	100g approx.	470g approx.	260g approx.	160g approx.
Accessories	9090 (Carrying Case) LR-44×2 Instruction Manual	7107(Test Leads) 8201(Output Plug) 9094(Carrying Case) R6P(AA)×2 Instruction Manual	7066(Test Leads) 9097(Carrying Case) R03(1.5V)×2 Instruction Manual	7066(Test Leads) 9066(Carrying Case) R6P(AA)×2 Instruction Manual
Optional	8004/8008 (Multi-Tran) 8021(Energizer)	8008(Multi-Tran) 7014(Output Cord)	8004/8008(Multi-Tran) 8021(Energizer)	8004/8008(Multi-Tran) 8021(Energizer)